

LONG NOZZLES WITH WHITE O-RING TEFLON:

Step 1: insert the white o-ring between the two grooves



Step 2: insert the nozzle holder from the longest side of the nozzle



SHORT NOZZLES WITH WHITE O-RING TEFLON:

Step 1: insert the white o-ring teflon between the two grooves



Step 2: insert the nozzle holder from the shortest side of the nozzle



LONG NOZZLES WITH BLACK O-RING

Insert the O-ring from the groove's side as shown in the first photo, then insert the nozzle holder from the same side

